



ARCCOS

**Arccos** Air

**QUICK START GUIDE**

# Table of Contents

- 04** Turning on Arccos Air
- 06** Pairing Arccos Air
- 08** Starting a Round
- 10** During a Round
- 12** After a Round
- 14** Charging & Storage
- 15** Glossaries
- 19** Compatability
- 20** Tips & Tricks
- 21** Help



## STEP 1

# Turning on Arccos Air

To power on Arccos Air device, slide the power switch so that the switch displays green. Once the device powers on, you will see the light turn on.

**NOTE:** Once the device has successfully gone through the pairing process, we recommend turning your Arccos Air on prior to the first tee so it has time to properly acquire a GPS signal.



9:41

Arccos Air Setup



Your Arccos Air was paired successfully.

Would you like to use Arccos Air for shots this round?

Yes, Use Arccos Air This Round

No, I'll use it another time.



## STEP 2

# Pairing Arccos Air

- Enable Bluetooth on your phone and open the Arccos app.\*
- Connect Arccos Air if prompted in the app.
- If not prompted, on the "Start Round" screen of the app, tap "Pair Air."
- Proceed by tapping "Air" on Start Round page under shot detection mode > "Pair Your Arccos Air" > "Yes, Use Arccos Air This Round"

\*Pairing will not happen in the phone's Bluetooth settings.

9:41



🔍 Search courses

Tamarack CC

Greenwich CT | 10 holes

18 Holes | 72 Par



Step 1 of 3

## Starting Round



89%

Optimizing Arccos Air's GPS Accuracy...

We're combing the skies to find as many satellites as possible for your round.

## STEP 3

# Starting a Round

- On the 'Start Round' screen, select your course, and tap "Start Round."
- Wait for Arccos Air to optimize GPS accuracy, then you can put your phone away.
- For the best experience, place Arccos Air in the front lead pocket.



## During a Round

- Play with Arccos Air in your front lead pocket to automatically record and sync shots. The device seamlessly streams data to the Arccos app via Bluetooth when in range, allowing review at any time.
- Arccos Air features a button for easily marking the pin location, enhancing the accuracy of approach, short game, and putting stats. To mark the pin, stand still next to the hole while pressing the button on the device.

9:41



### Syncing Shots From Last 24m...

Your round will automatically close when the sync is finished.

Make sure to keep your Arccos Air close by, and powered on. Ending your round without syncing will result in lost shots.

End Round Without Syncing

## After a Round

- To finish syncing, end the round on the Arccos app.
- Wait until Arccos Air has completed the syncing process.
- Turn off Arccos Air and place it in the Charging Case so it's ready for your next round. If Arccos Air is left on when you put it in the case, it will automatically turn off. When you take it out, turn it back on by pressing the Flag button, or by switching the power off and back on.














# Charging & Storage

- If you put Arccos Air in the Charging Case while it's still on, it will turn off automatically after 5 minutes. To turn it back on, press the Flag button or toggle the power switch.
- When you place Arccos Air in the Charging Case, the LEDs will light up. They stay on while charging and turn off once the device is fully charged.
- To charge the Charging Case use the included USB-C cord. It will take ~4 hrs to fully charge in normal conditions.
- For optimal charging, please plug into a wall outlet using a reliable AC adapter. Charging the case via a computer USB will not be sufficient.

# LED Glossary

For Arccos Air Wearable

LED	BLINKING	SOLID
	 GPS Signal  Phone Connection	 GPS Signal  Phone Connection
	 GPS Signal  Phone Connection	 GPS Signal  Phone Connection
	Battery at 20% Or Less	Updating Firmware

# LED Glossary

## For Arccos Air Charging Case

### CHARGING ARCCOS AIR

LED (WHITE)*	CHARGE %
○○○○	Battery Between 75% - 100%
○○○	Battery Between 50% - 75%
○○	Battery Between 25% - 50%
○	Battery at 25% Or Less
⦿	Blinking at 10% or Less

### CHARGING THE CHARGING CASE

LED	BLINKING	SOLID
○	Charging	Fully Charged

\*Each LED represents 25% charge

9:41



Arccos Air

Smart Laser



Arccos Air Connected & Ready



GPS SIGNAL



BLUETOOTH



BATTERY

Switch Detection to Phone

# App Icon Glossary

For Arccos Air-Related Items in App

## IN-PLAY SCREEN



Device Is Connected



Syncing Data



Device Has Low Battery



Device Has No GPS



Device Is Disconnected

## START ROUND SCREEN



Alert - Tap To View



Device Is Disconnected

# Compatibility

Arccos Air is designed exclusively for users of the Arccos platform. Smart Sensors are not required however Arccos Air is compatible with Arccos Smart Sensors, andt Arccos Smart Grips using the Arccos app.

Arccos Air requires a member to have the Arccos App installed on their smartphone and have an active subscription.

For more information and a list of supported devices and platforms, visit [support.arccosgolf.com](https://support.arccosgolf.com).

# Tips & Tricks

Visit [support.arccosgolf.com](https://support.arccosgolf.com) for more

- Keep Arccos Air in your front pocket to ensure accurate shot detection.
- If the Arccos Air LED turns red, it means your device has low battery.
- When the Charging Case is fully charged it will power Arccos Air for up to 12 rounds of golf.

# Need Help?

Contact our Customer Experience team anytime for assistance.

Phone: 1-844-692-7226

Email: [starter@arccosgolf.com](mailto:starter@arccosgolf.com)

Website: [www.arccosgolf.com](http://www.arccosgolf.com)

Support: [support.arccosgolf.com](http://support.arccosgolf.com)

Address: 700 Canal St, Stamford, CT 06902

## FCC REGULATORY COMPLIANCE

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation.

If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try and correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

Warning: Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

## ISED REGULATORY COMPLIANCE

This device contained license-exempt transmitter(s)/receiver(s) that comply with Innovation, Science and Economic Development Canada's license-exempt RSS(s).

Operation is subject to the following two conditions:

1. This device may not cause interference.
2. This device must accept any interference, including interference that may cause undesired operation of the device.

This equipment complies with IC RSS-102 radiation exposure limits set forth for an uncontrolled environment. This transmitter must not be co-located or operating in conjunction with any other antenna or transmitter.

L'émetteur exempté de licence contenu dans cet appareil est conforme à la Innovation, Sciences et Développement économique Canada RSS pour la radio NFC Dispositifs.

L'exploitation est permise dans les deux conditions suivantes :

1. Le dispositif ne doit pas causer d'interférences;
2. L'équipement doit accepter toute interférence reçue, même si l'interférence peut nuire à son fonctionnement.

Cet équipement est conforme aux limites d'exposition aux rayonnements IC CNR-102 établies pour un environnement non contrôlé. Cet émetteur ne doit pas être localisé ou exploité en conjonction avec toute autre antenne ou émetteur.

The license-exempt transmitter contained in this device complies with the Innovation, Science and Economic Development Canada RSS for NFC Radio Devices. Operation is permitted under both of the following conditions:

1. The device must not cause interference;
2. The equipment must accept any interference received, even if the interference may impair its operation.

This equipment complies with IC CNR-102 radiation exposure limits established for an uncontrolled environment. This transmitter must not be located or operate in conjunction with any other antenna or transmitter.



[www.arccosgolf.com](http://www.arccosgolf.com)

FCC ID: 2ACQZ-L3P

L3P IC:12164A-L3P



Japan Radio Law Compliance



R 210-220079

Declaration for EU Compliance

Operation Frequency Band/Max. RF power transmitted: 2402-2480MHz, -6dBm

802403